



WARNING

BEFORE STARTING!!

**INSURE FIREARM IS UNLOADED AND CHAMBER IS CLEARED
CAREFULLY READ INSTRUCTIONS BEFORE PROCEEDING
REMOVE UPPER RECEIVER ASSEMBLY
WEAR SAFETY GLASSES TO PREVENT EYE INJURY
BE MINDFUL OF SMALL PARTS AND SPRINGS**

NOTE:

**THE BUFFER TUBE COVER WILL FIT ANY
RIFLE OR PISTOL BUFFER TUBE BETWEEN
1.16" AND 1.18" IN DIAMETER. DAMAGE
DUE TO INSTALLATION ON AN OVERSIZED
TUBE WILL VOID WARRANTY.**

1. Remove tube support bar and discard.
(looks like a comb)
2. Slide Buffer Tube Cover onto buffer tube.
3. Insert steel clamping spacers into holes in clamping block and drop in place with the thin edge facing the castle nut (FIG 1).

NOTE: Spacers are loose in the holes to allow for greater compatibility with various buffer tube manufacturers.

3. Using two 1/16 allen wrenches install and tighten screws on each side until snug (FIG 2). Blue Loctite is optional.

Installation video is available on our Youtube page:
<https://www.youtube.com/watch?v=FM03ylbdwpo>

